

## Cadence Battery Replacement Instructions

Materials needed: Jewelers Screwdriver Size # 00, Precision tweezers, one lithium CR 2032 watch battery



**Step 1.** Remove the four screws from the stainless steel case back of the watch with a Jewelers screwdriver



**Step 2.** Remove the stainless steel case back from the watch



**Step 3.** Remove the clear plastic tape from the watch assembly. Once the tape is removed from the watch assembly, discard the tape. (*Do not to take the assembly out of the watch*)



**Step 4.** Unlatch the clip covering the CR 2032 battery



**Step 5.** Remove and replace the CR 2032 battery with a new lithium battery



**Step 6.** Check the clips next to each button to make sure they are still aligned properly



**Step 7.** Place the case back onto the watch (Make sure the writing on the back of the watch is not upside down)



**Step 8.** Securely tighten the four screws so the case back is flush with the watch .



**NK**  
**NIELSEN-KELLERMAN**

'REMO' 206 Cowans Lane  
Oxley Island NSW 2430  
Ph 02 6553 2473  
Fax 02 6553 2544  
www.nkhome.com  
info@nkhome.com